MARTINDALE ELECTRIC

BARCCD Barcode Reader Configuration

The BARCCD barcode reader has been configured to work with the Martindale MicroPat+ PAT testers and should require no further re-configuration. If at any time you have problems, it may be that the reader has reverted to its factory pre-set settings. In this case the following configuration procedure can be performed quickly.

To configure the reader scan the barcodes below, in order (from 1 through to 5). The barcode reader will beep after reading each code. Ensure PAT is set to 1200 baud rate.

1

Restore Default

2

RS232

3

Enter Configuration

4

1200 Baud

5

Exit & Save Configuration

Due to policy of continuous development, Martindale Electric reserves the right to alter equipment specification and description outlined in this document without prior notice. No part of this document shall be deemed to be part of any contract for the equipment unless specifically referred to as an inclusion within such contract. ©Martindale Electric Co. Ltd. 2002

Martindale Electric Company Ltd.
Metrohm House, Penfold Trading Estate, Imperial Way, Watford, WD24 4YY. Tel: 01923 441717 Fax: 01923 446900
E-mail: sales@martindale-electric.co.uk Web site: http://www.martindale-electric.co.uk