Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.

Laser Pen Instructions

Turn the bottom of the pen clockwise to use the nib as a PDA scribe and anti-clockwise for a pen.

To replace the batteries turn the top of the pen counter clockwise and insert the three batteries with plus symbol visible.

WARNING
Do not point the laser at anyone's eyes as this could cause blindness.